

## CHARGING BUCKETS

### Efficient and Consistent Mop Impregnation

Compatible with our Saturix Hands-Free Mop Drop System, these robust charging buckets evenly saturate up to 10 mops at a time. They can be used with Saturix cleaning carts or stand alone.



### Features and Benefits

#### Plastic Bucket:

- Arched bottom facilitates easy mop attachment
- Evenly saturates up to 10 Saturix mops
- Reduced cleaning solution waste
- Improved efficiency and outcomes

#### Stainless Steel Bucket

- Auto-clavable at least 50 cycles
- Arched insert facilitates easy mop attachment
- Evenly saturates up to 10 Saturix mops
- Can be used as a container to auto-clave mops
- Reduced cleaning solution waste
- Improved efficiency and outcomes

Item	Description	Dimensions (LxWxH)	Weight	Cleanroom Level Recommendation*
HCA01	Plastic Charging Bucket, Blue	20" x 7" x 10" (50 cm x 17 cm x 25 cm)	2 lbs / 1.1 kg	ISO 3 4 5 6 7 8
HCA02	Stainless Steel Charging Bucket	20" x 7" x 9" (51 cm x 18.5 cm x 23.5 cm)	8 lbs / 3.8 kg	ISO 3 4 5 6 7 8

#### Visionary Cleaning System

Saturix is a complete system for critical cleaning featuring innovative carts, mops and wipes backed by 100 years of cleaning experience. With focused product selection, it's easy to find exactly what you need right now.

To learn more about our products, visit us online at [Saturix.com](http://Saturix.com) or contact us at +1 (413) 598-8344 or [info@saturix.com](mailto:info@saturix.com)



# HOW TO USE SATURIX CHARGING BUCKETS



1. For **Stainless Steel Charging Buckets**, place the Arched Insert in the bucket.
2. Determine the appropriate volume of cleaning solution per mop load and pour it into the charging bucket.
  - The table below is a starting guide, test what works best for you.
  - The correct volume of solution will provide max coverage with virtually no liquid waste.
3. Insert the appropriate number of mops (up to 10 mops) with the pockets facing up.
4. For **Stainless Steel Charging Buckets**, secure the two latches to create a seal.  
For the **Plastic Charging Buckets**, press all four tabs until you hear an audible click.
5. Turn the bucket upside down and wait 5 to 10 minutes for saturation.
6. Turn the bucket over, remove the lid and use.

## TIPS TO ENHANCE EFFICIENCY AND OUTCOMES

For **Plastic Charging Buckets**, clean with IPA after use and store dry.

For **Stainless Steel Charging Buckets**, ensure they are dried after use.

- If you use a chlorine-based cleaning solution, clean the bucket with water and dry with wipes.
- Replace the rubber gasket on the Stainless Steel Charging bucket after 50 auto-clave cycles.

**Either type of bucket** can be used alone for cleanrooms and critical environments that have space constraints.

Saturix Mop	SKU Number	Cleaning Solution per Mop	Floor Coverage per Mop
Heavy Weight Disposable Microfiber Mops	MD416, MD416S	250 ml	305 ft <sup>2</sup> / 27 m <sup>2</sup>
Medium Weight Disposable Microfiber Mops	MD316, MD316S	200 ml	228 ft <sup>2</sup> / 20 m <sup>2</sup>
Light Weight Disposable Microfiber Mops	MD216, MD216S	130 ml	158 ft <sup>2</sup> / 14 m <sup>2</sup>
Reusable Microfiber Mops	MR816, MR816A	400 ml	222 ft <sup>2</sup> / 20 m <sup>2</sup>

\* Cleanroom class recommendations are based on typical industry-wide applications and general cleanliness classifications. Please consult our experienced FG Clean Wipes sales representatives for specific cleanroom selections for critical and/or specialized applications based on a wider selection of criteria.

To learn more about our products, visit us online at [Saturix.com](http://Saturix.com) or contact us at +1 (413) 598-8344 or [info@saturix.com](mailto:info@saturix.com).

